

## Enrolling Detectors

Step	Description
1	In the installer menu navigate to System - Devices / Zones - Desired Zone - Device - Enrol safety device and then press OK.
2	Remove the detector from the mounting plate.
3	Press and hold the tamper switch on the rear of the detector until the LED flashes then release.
4	Press and release the tamper again ( the LED flashes rapidly ). The panel will confirm that the device is enrolled ( allow 20 seconds )
5	Re-attach the detector to the mounting plate.



## Contents

Enrolling Detectors

**GSD))) i70**

Carbon Monoxide Detector  
Heat Detector  
Smoke Detector